

PNÖMATİK BAĞLANTI EKİPMANLARI

PLASTİK SERİ PNÖMATİK BAĞLANTI EKİPMANLARI

→ MİNİ SERİ PNÖMATİK BAĞLANTI EKİPMANLARI

PARÇA NO.	R/M	ØD
PRDM-M5-4	M5	4
PRDM-M5-6	M5	6
PRDM-1/8-4	1/8	4
PRDM-1/8-6	1/8	6

PARÇA NO.	R/M	ØD
PRDM-M3-4	M3	4
PRDM-M5-4	M5	4
PRDM-M5-6	M5	6
PRDM-M6-4	M6	4
PRDM-M6-6	M6	6
PRDM-1/8-4	1/8	4
PRDM-1/8-6	1/8	6

PARÇA NO.	R/M	ØD
PRLM-M3-4	M3	4
PRLM-M5-4	M5	4
PRLM-M5-6	M5	6
PRLM-M6-4	M6	4
PRLM-M6-6	M6	6
PRLM-1/8-4	1/8	4
PRLM-1/8-6	1/8	6

PARÇA NO.	R/M	ØD
PRLUM-M5-4	M5	4
PRLUM-M5-6	M5	6
PRLUM-1/8-4	1/8	4
PRLUM-1/8-6	1/8	6

PARÇA NO.	ØD
PRTM-4	4
PRTM-6	6

PARÇA NO.	ØD
PRYM-4	4
PRYM-6	6

PARÇA NO.	R/M	ØD
PRTYM-M5-4	M5	4
PRTYM-M5-6	M5	6
PRTYM-1/8-4	1/8	4
PRTYM-1/8-6	1/8	6

PARÇA NO.	R/M	ØD
PRTOM-M5-4	M5	4
PRTOM-M5-6	M5	6
PRTOM-1/8-4	1/8	4
PRTOM-1/8-6	1/8	6

- KOLAY ve HIZLI MONTAJ
- KOMPAKT ve HAFİF
- ZENGİN ÜRÜN SECENEĞİ
- GENİŞ HORTUM ARALIĞI
Ø 4 mm - Ø 16 mm

→ STANDART SERİ PNÖMATİK BAĞLANTI EKİPMANLARI

PARÇA NO.	R/M	ØD
PRD-1/8-4	1/8	4
PRD-1/4-4	1/4	4
PRD-1/8-6	1/8	6
PRD-1/4-6	1/4	6
PRD-3/8-6	3/8	6
PRD-1/8-8	1/8	8
PRD-1/4-8	1/4	8
PRD-3/8-8	3/8	8
PRD-1/2-8	1/2	8
PRD-1/8-10	1/8	10
PRD-1/4-10	1/4	10
PRD-3/8-10	3/8	10
PRD-1/2-10	1/2	10
PRD-1/4-12	1/4	12
PRD-3/8-12	3/8	12
PRD-1/2-12	1/2	12
PRD-1/4-16	1/4	16
PRD-3/8-16	3/8	16
PRD-1/2-16	1/2	16

PARÇA NO.	R/M	ØD
PRDA-M5-4	M5	4
PRDA-1/8-4	1/8	4
PRDA-1/4-4	1/4	4
PRDA-M5-6	M5	6
PRDA-1/8-6	1/8	6
PRDA-1/4-6	1/4	6
PRDA-3/8-6	3/8	6
PRDA-1/8-8	1/8	8
PRDA-1/4-8	1/4	8
PRDA-3/8-8	3/8	8
PRDA-1/2-8	1/2	8
PRDA-1/8-10	1/8	10
PRDA-1/4-10	1/4	10
PRDA-3/8-10	3/8	10
PRDA-1/2-10	1/2	10
PRDA-1/4-12	1/4	12
PRDA-3/8-12	3/8	12
PRDA-1/2-12	1/2	12
PRDA-1/4-16	1/4	16
PRDA-3/8-16	3/8	16
PRDA-1/2-16	1/2	16

PARÇA NO.	R/M	ØD
PRDD-1/8-4	1/8	4
PRDD-1/4-4	1/4	4
PRDD-1/8-6	1/8	6
PRDD-1/4-6	1/4	6
PRDD-3/8-6	3/8	6
PRDD-1/8-8	1/8	8
PRDD-1/4-8	1/4	8
PRDD-3/8-8	3/8	8
PRDD-1/2-8	1/2	8
PRDD-1/8-10	1/8	10
PRDD-1/4-10	1/4	10
PRDD-3/8-10	3/8	10
PRDD-1/2-10	1/2	10
PRDD-1/4-12	1/4	12
PRDD-3/8-12	3/8	12
PRDD-1/2-12	1/2	12

PARÇA NO.	R/M	ØD
PRL-M5-4	M5	4
PRL-1/8-4	1/8	4
PRL-1/4-4	1/4	4
PRL-1/8-6	1/8	6
PRL-1/4-6	1/4	6
PRL-3/8-6	3/8	6
PRL-1/8-8	1/8	8
PRL-1/4-8	1/4	8
PRL-3/8-8	3/8	8
PRL-1/2-8	1/2	8
PRL-1/8-10	1/8	10
PRL-1/4-10	1/4	10
PRL-3/8-10	3/8	10
PRL-1/2-10	1/2	10
PRL-1/8-12	1/8	12
PRL-1/4-12	1/4	12
PRL-3/8-12	3/8	12
PRL-1/2-12	1/2	12
PRL-1/4-16	1/4	16
PRL-3/8-16	3/8	16
PRL-1/2-16	1/2	16

PARÇA NO.	R/M	ØD
PRLU-M5-4	M5	4
PRLU-1/8-4	1/8	4
PRLU-1/4-4	1/4	4
PRLU-1/8-6	1/8	6
PRLU-1/4-6	1/4	6
PRLU-3/8-6	3/8	6
PRLU-1/8-8	1/8	8
PRLU-1/4-8	1/4	8
PRLU-3/8-8	3/8	8
PRLU-1/2-8	1/2	8
PRLU-1/8-10	1/8	10
PRLU-1/4-10	1/4	10
PRLU-3/8-10	3/8	10
PRLU-1/2-10	1/2	10
PRLU-1/4-12	1/4	12
PRLU-3/8-12	3/8	12
PRLU-1/2-12	1/2	12

PARÇA NO.	R/M	ØD
PRLD-1/8-4	1/8	4
PRLD-1/4-4	1/4	4
PRLD-1/8-6	1/8	6
PRLD-1/4-6	1/4	6
PRLD-3/8-6	3/8	6
PRLD-1/8-8	1/8	8
PRLD-1/4-8	1/4	8
PRLD-3/8-8	3/8	8
PRLD-1/2-8	1/2	8
PRLD-1/8-10	1/8	10
PRLD-1/4-10	1/4	10
PRLD-3/8-10	3/8	10
PRLD-1/2-10	1/2	10
PRLD-1/4-12	1/4	12
PRLD-3/8-12	3/8	12
PRLD-1/2-12	1/2	12

PARÇA NO.	R/M	ØD
PRTY-M5-4	M5	4
PRTY-1/8-4	1/8	4
PRTY-M5-6	M5	6
PRTY-1/8-6	1/8	6
PRTY-1/4-6	1/4	6
PRTY-3/8-6	3/8	6
PRTY-1/8-8	1/8	8
PRTY-1/4-8	1/4	8
PRTY-3/8-8	3/8	8
PRTY-1/2-8	1/2	8
PRTY-1/8-10	1/8	10
PRTY-1/4-10	1/4	10
PRTY-3/8-10	3/8	10
PRTY-1/2-10	1/2	10
PRTY-1/4-12	1/4	12
PRTY-3/8-12	3/8	12
PRTY-1/2-12	1/2	12

PARÇA NO.	R/M	ØD
PRTO-M5-4	M5	4
PRTO-1/8-4	1/8	4
PRTO-M5-6	M5	6
PRTO-1/8-6	1/8	6
PRTO-1/4-6	1/4	6
PRTO-3/8-6	3/8	6
PRTO-1/8-8	1/8	8
PRTO-1/4-8	1/4	8
PRTO-3/8-8	3/8	8
PRTO-1/2-8	1/2	8
PRTO-1/8-10	1/8	10
PRTO-1/4-10	1/4	10
PRTO-3/8-10	3/8	10
PRTO-1/2-10	1/2	10
PRTO-1/4-12	1/4	12
PRTO-3/8-12	3/8	12
PRTO-1/2-12	1/2	12

PARÇA NO.	R/M	ØD
PRYO-M5-4	M5	4
PRYO-1/8-4	1/8	4
PRYO-M5-6	M5	6
PRYO-1/8-6	1/8	6
PRYO-1/4-6	1/4	6
PRYO-3/8-6	3/8	6
PRYO-1/8-8	1/8	8
PRYO-1/4-8	1/4	8
PRYO-3/8-8	3/8	8
PRYO-1/2-8	1/2	8
PRYO-1/8-10	1/8	10
PRYO-1/4-10	1/4	10
PRYO-3/8-10	3/8	10
PRYO-1/2-10	1/2	10
PRYO-1/4-12	1/4	12
PRYO-3/8-12	3/8	12
PRYO-1/2-12	1/2	12

PARÇA NO.	R/M	ØD
PRDDP-1/8-4	1/8	4
PRDDP-1/4-4	1/4	4
PRDDP-1/8-6	1/8	6
PRDDP-1/4-6	1/4	6
PRDDP-3/8-6	3/8	6
PRDDP-1/8-8	1/8	8
PRDDP-1/4-8	1/4	8
PRDDP-3/8-8	3/8	8
PRDDP-1/2-8	1/2	8
PRDDP-1/8-10	1/8	10
PRDDP-3/8-10	3/8	10
PRDDP-1/2-10	1/2	10
PRDDP-1/4-12	1/4	12
PRDDP-3/8-12	3/8	12
PRDDP-1/2-12	1/2	12

PARÇA NO.	ØD
PRP-4	4
PRP-6	6
PRP-8	8
PRP-10	10
PRP-12	12

PARÇA NO.	ØD
PRT-4	4
PRT-6	6
PRT-8	8
PRT-10	10
PRT-12	12
PRT-16	16

PARÇA NO.	ØD	ØD
PRDT-4-4-4	4	4
PRDT-4-6-6	4	6
PRDT-8-4-6	8	6
PRDT-6-8-8	6	8
PRDT-10-8-8	10	8
PRDT-8-10-10	8	10
PRDT-12-10-10	12	10
PRDT-10-12-12	10	12

PARÇA NO.	ØD
PRY-4	4
PRY-6	6
PRY-8	8
PRY-10	10
PRY-12	12
PRY-16	16

PARÇA NO.	ØD	ØD
PRYD-4-4	4	4
PRYD-6-6	6	6
PRYD-8-8	8	8
PRYD-10-10	10	10
PRYD-12-10	12	8

PARÇA NO.	ØD
PRQ-4	4
PRQ-6	6
PRQ-8	8
PRQ-10	10
PRQ-12	12

PARÇA NO.	ØD
PRHK-4	4
PRHK-6	6
PRHK-8	8
PRHK-10	10
PRHK-12	12
PRHK-16	16

PARÇA NO.	ØD
PRK-4	4
PRK-6	6
PRK-8	8
PRK-10	10
PRK-12	12

PARÇA NO.	R/M	ØD
PR2D-1/8-4	1/8	4
PR2D-1/4-4	1/4	4
PR2D-3/8-6	3/8	6
PR2D-1/8-8	1/8	8
PR2D-1/4-8	1/4	8
PR2D-3/8-8	3/8	8
PR2D-1/4-10	1/4	10
PR2D-3/8-10	3/8	10
PR2D-1/2-10	1/2	10
PR2D-3/8-12	3/8	12
PR2D-1/2-12	1/2	12

PARÇA NO.	R/M	ØD
PR3D-1/8-4	1/8	4
PR3D-1/4-4	1/4	4
PR3D-3/8-6	3/8	6
PR3D-1/8-8	1/8	8
PR3D-1/4-8	1/4	8
PR3D-3/8-8	3/8	8
PR3D-1/4-10	1/4	10
PR3D-3/8-10	3/8	10
PR3D-1/2-10	1/2	10
PR3D-1/4-12	1/4	12
PR3D-3/8-12	3/8	12
PR3D-1/2-12	1/2	12






PARÇA NO.	R/M	ØD
PR4D-1/8-4	1/8	4
PR4D-1/4-4	1/4	4
PR4D-3/8-6	3/8	6
PR4D-1/8-8	1/8	8
PR4D-1/4-8	1/4	8
PR4D-3/8-8	3/8	8
PR4D-1/4-10	1/4	10
PR4D-3/8-10	3/8	10
PR4D-1/2-10	1/2	10
PR4D-1/4-12	1/4	12
PR4D-3/8-12	3/8	12
PR4D-1/2-12	1/2	12

PARÇA NO.	R/M	ØD
PR4D-1/8-6	1/8	6
PR4D-1/4-6	1/4	6
PR4D-3/8-8	3/8	8
PR4D-1/8-10	1/8	10
PR4D-1/4-10	1/4	10
PR4D-3/8-10	3/8	10
PR4D-1/2-10	1/2	10
PR4D-1/4-12	1/4	12
PR4D-3/8-12	3/8	12
PR4D-1/2-12	1/2	12

PARÇA NO.	ØD
PRNL-4	4
PRNL-6	6
PRNL-8	8
PRNL-10	10
PRNL-12	12
PRNL-16	16

NİPEL

PARÇA NO.	ØD
PRN-4	4
PRN-6	6
PRN-8	8
PRN-10	10
PRN-12	12
PRN-16	16



PNÖMATİK BAĞLANTI EKİPMANLARI



PNÖMATİK OTOMASYONDA TEK MARKA, KOMPLE ÇÖZÜM

60 YIL

Pemaks®
Pnömatik
pemaks.com.tr